

The Brewer

Kiehna®

CARE AND USE GUIDE
VACUUM INSULATED
STAINLESS STEEL BOTTLE

GENERAL CARE

- Before first use, wash all parts with warm soapy water. Rinse all parts thoroughly and allow time to dry.
- Contents should not be left in the container for longer than 24 hours. Wash with clean water as soon as possible after each use. Allow all parts to dry completely prior to next use or storage.
- DO NOT use abrasive cleaners or scrubbers since they may dull or damage the finish.
- DO NOT use bleach or cleaners containing chlorine on any parts of the product.
- This product is hand-wash only and is not suitable for use in a dishwasher or microwave.
- DO NOT immerse or soak in water for prolonged periods of time. Residual liquids, food, or other contents may become trapped between product components, such as lid parts, container parts, seals (flexible silicone band around lid and/or stopper), or straws (if present). Hand washing is recommended to ensure that all parts of the product are thoroughly cleaned.
- For maximal thermal efficiency, pre-chill the product just prior to use by filling with cold tap water, attach lid, let stand for 5-10 minutes and empty water. Then fill it with your preferred contents and re-cover with lid to increase thermal efficiency. Repeat these steps with hot water for hot contents.
- Always test the temperature of the contents before consuming.
- DO NOT use with carbonated drinks or fill with alcohol or corrosive liquids.

- DO NOT expose to open flame or high temperatures.
- Not recommended for use by children. Keep out of reach of children, especially when product contains hot contents, which may burn or scald.
- CAUTION: Avoid overfilling the cup. Fill bottle to a maximum of 2-3 cm from rim. Hot contents may burn or scald if it overflows.
- Regularly check for worn, damaged or missing silicone seal, which may otherwise cause leak of hot contents.
- This bottle may break when dropped. Bottle is pressure tested but under excess pressure, the bottle may crack or distort.
- Please retain this information for future reference."

ASSEMBLY & USE

1. Remove lid (A) by twisting anticlockwise.
2. Remove silicone seal around the lid (A1).
3. Wash all parts separately and re-assemble once completely dry.
 - A. Ensure silicone seal (A1) is properly seated to minimise leaking.
4. Fill container with contents. Do not overfill: leave 2-3cm of space to avoid overflow.
5. Replace the lid (A) by twisting it clockwise.
6. To drink, lift the flip lid (B) and lock it to the back of the lid (B) using the notch (B1).
7. When finished drinking, lift the flip lid (B) from the notch (B1) and press it firmly to the front of the lid.

